



## HOW TO USE YOUR PAVERS M8

Follow these 5 simple steps

After you have prepared your patio area with sub-base use the Pavers M8 as follows:

1. Using your Pavers M8 as a normal level with the screed attachment out, lay your first datum paver, if you are laying smaller size pavers such as block paving then ensure you lay a few to make up around 450mm squared. Take your time to do this ensuring you have the desired fall you require as this will be the bench mark for the rest of the project.
2. Insert the screed into the bottom of the level ensuring the measuring increments are at the back, which is the opposite side to the logo on the tool. This is to ensure the tapper on the screed is facing you and to stop the increment marking being distorted when screeding. Using the increments tighten the adjusters to suite the depth of paving you are laying (hand tight).
3. Attach the ware-plate this is to avoid scratching the paving and the tool. This plate is made from abrasion resistant plastic which also helps the tool to glide with ease across the surface of the paving. Over time these will wear out and replacements are available.
4. You are now ready to lay the rest of your project. Place the screed next to the datum paver where you intend to start paving.
5. Now place the wear plate end of the Pavers M8 onto the datum paver then, simply drag the screed level across the surface of the datum paver by slightly pushing down on the datum paver end ensuring the ware plate stays firmly flat on the paver. While lightly holding the other end as to guide it nicely across, you can also check by keeping an eye on the vial to see how you are progressing. Once you have done this you will have the perfect bed every time. As long as your datum paver is right and you screed from that point with the ware plate flat you will have a perfect result.

### Handy Tips

When screeding with just grit sand i.e. no cement as you would for block pavers then you set the datum 5/8mm higher than the finish level you want, so that when you use a compactor then all your pavers will compact down evenly.

However, when using a cement screed set your datum paver at the finish level you require and then set your screed 5/8mm higher, so after each screed when you lay your paver you can give a little tap in the centre just to bed the paver in.

Remember, because you have the perfect bed just tap the centre of the paver and this will settle in evenly.